


Underwater Light Wiring Diagram



Lights need to be wired in parallel (cannot be installed in series) with a direct power source running directly to each light. Wire gauge is determined by the light distance from power source and the numbers of lights on the circuit. Please refer to instruction sheets supplied with your product for installation information.